

Chemo Bag Construction

Materials:

2 - 12 1/2" x 6" pieces of fabric
1 - 48" piece of 3/4" ribbon or make a strap that size from fabric



Fold each piece of fabric so it is 6 1/4" x 6". Sew along side opposite the fold and one of the other edges.

Clip sewn corners. Turn one piece



Mark where the fold is along the top, add ribbon or fabric strap to each side of the inside out bag being careful to not twist the strap. Tuck strap inside.



Put other piece inside the first one, with right sides together. Sew top open edges with a 1/4" seam, leaving an opening to turn everything right side out.

Turn and tuck bag pieces together wrong sides together. Check to be sure strap did not get twisted - now is the time to fix it if it did.



Smooth everything out, iron along top 1 edge. Topstitch top edge to seal opening and reinforce strap.

You are done!