

Walker Caddy

Makes 1

All seams $\frac{1}{4}$ inch.



Questions: Jan McQueen 541-961-0915

Material needed: Quilting Cotton

4 - 10" by 12" Main body and back
4 - 6" by 12" Pockets
4 - 2 1/2" by 8" Straps

Heavy Fusible fleece 917 F or similar

2 - 10" by 12" Body
2 - 2 1/2" by 8" Straps
2 snaps or 2 - 1" piece Velcro

1. Fuse the interfacing to wrong sides of 2 main body and 2 strap pieces. Add quilting on fused main body pieces for optional fancy version.

2. Sew straps right sides together on both 8" sides, turn, press and top stitch near edges. Add more topstitching for optional fancy version. Make 2.




3. Sew pocket pieces right sides together on one 12" edges. Turn, press and top stitch close to edge. Optional extra stitching to quilt the pocket. Make 2.

4. Place pocket pieces on top of main body pieces, aligning raw bottom edge, Making sure the finished top edge of pocket are evenly spaced from top on both sides. Make 2. Pin or baste in place on sides.

5. Pin straps, right side together on top edge of 1 fused main body piece, 1 3/4" in from edges.



6. Pin 1 unfused body piece right sides together on top (see above right). Sew around the entire piece except between the straps on top edge, leaving an opening to turn it. Trim corners, turn getting corners square, press and top stitch around edge, this closes the seam opening on top edge.



7. Sew down the middle of 1 pocket - about 5 3/4" from sides, making 2 smaller pockets on this side leaving a large pocket on the other.

8. Place straps RST on top of other body piece, 1 3/4" from both edges, pin. Put last main body piece, RST, over straps and pin in place. Sew around this piece like the first, leaving opening between straps for turning. Trim corners, turn, press, top stitch. Almost done! HINT: Fold up first side inside the sandwich below.



9. Attach snaps or Velcro, 5/8" from sides and 2 " down from top edges, on both sides. Done, Jan will donate to locals Seniors in need.

Thanks.